ADDENDUM

60-8501/8502/8505/8506/8507/8512

Before installing your XMODs accessory, follow these steps to remove the batteries. Failure to remove the batteries can result in a short or circuit damage.

1. Turn off the controller and vehicle.
2. Detach the car body.
3. Remove the batteries from the vehicle chassis.
4. Remove the antenna.
5. Proceed with installation as described in your user's guide.

©2004 RadioShack Corporation
All Rights Reserved.
RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

www.xmodsRC.com

Printed in China
07A04